



NOTE - SECTIONS

- Section Points on Plan - Refer to DR0001 to DR0004.
- Detail Cross Sections - Refer to DR0111 to DR0114.
- The direction of all sections is from upstream to downstream

1m SCALE 1:100